Vivardis 😾	Nivolis-ANTON Firmware Update Instructions		
	VIVARDIS: QMS - template (QMS)	Date: 20240816 10:33	
	Document: DOC-PROC13 - Work Instructions	Page: 1 / 4	

1. AUDIT TRAIL

Version	Change Description	Change Date
01	Initial Version	2023/05/05
02	Updated + translated version	2024/07/31
03	Updated by adding picture for microusb connection on PCB	2024/08/16

2. SIGNATURES

Signature Meaning	Name	Title	Date	Signature
Author	Gerard Evers	CEO	20240731	

3. WORK INSTRUCTIONS TO UPDATE NIVOLIS ANTON FIRMWARE

Remove Nivolis-Anton from the	Retirer tous les cables entre Nivolis-
Sentec / Radiometer monitor	Anton et les moniteurs Sentec ou
	Radiometer
Remove Nivolis-Anton from the	Retirer Nivolis-Anton de la
wireless charging platform	plateforme de charge
Switch on the Nivolis-Box Wifi	Allumez le routeur Wifi-4G
Router	NivolisBox
Open Nivolis-Anton by unscrewing the 4 screws at the bottom	Ouvrir Nivolis-Anton en dévissant les 4 vis sous le dispositif
Remove the cover	Retirer le couvercle

All dates and times are in the project's default time zone and formatting.

	Nivolis-ANTON Firmware Update Instructions			
Vivardis 🜌	VIVARDIS: QMS - template (QMS) Date: 202			
	Document: DOC-PROC13 - Work Instructions	Page: 2 / 4		
-	Locate and remove the Micro-USB Sit	uer et retirer le câble plat Micro-		
	flat ribbon cable going from below US	B partant de sous la batterie à la		
Aurus.	the battery to the electronic board car	te électronique		
Company of the second s				
Contraction of the local division of the loc				
r	Connect a microUSB cable to this Bra	ancher Anton sur le PC par le		
In the second	connector on the electronic board cal	ole USB micro USB connecté à la		
TR	and on a free USB connector on car	te électronique		
	your computer			
None 1				
N MOT				
Statement of the local division of the local				
and the second second second second				
	Ensure you do not have any other As	surez-vous de ne pas avoir		
	device connected to your PC that d'a	utres équipement susceptible de		
	might create a serial cre	er un port de communication		
	communication port sér	ie branché sur votre ordinateur		
	Open the folder Anton_FW_Last Ou	vrir le dossier Anton_FW_Last		
	and double click to execute the pu	is double cliquer pour exécuter		
	script 20240731Anton.bat. 20	240/31Anton.bat.		
	Verify the progress of the update Vé	rifier la progression de la mise à		
	iou	ır		

Nivolis-ANTON Firmware Update Instructions				ns
Vivardis 🜌	,	VIVARDIS: QMS - template (QMS)		Date: 20240816 10:33
	Docur	nent: DOC-PROC13 - Work Instructions		Page: 3 / 4
C:\Windows\system	2\cmd.exe			– 🗆 ×
esptool write_flash:	error: argument <a< td=""><td>ddress> <filename>: [Errno 2] No such file</filename></td><td>or directo</td><td>ry: 'NivolisAnton_2022.bin' 🔺</td></a<>	ddress> <filename>: [Errno 2] No such file</filename>	or directo	ry: 'NivolisAnton_2022.bin' 🔺
C:\DocWork\2021_VI	VA\Firmware\Ant	on>20240731Anton.bat		
C:\DOCWOrK/2021_VIVA\Firmware\AntOn/20240/31AntOn.bat C:_DOcWork/2021_VIVA\Firmware\AntOn/20240/31AntOn.bat C:_DocWork/2021_VIVA\Firmware\AntOn/20240/31AntOn.bat C:_DocWork/2021_VIVA\Firmware\AntOn/20240/31AntOn.bat Prite_Flashflash_mode dioflash_freq 40mflash_size 16MB 0x1000 bootloader.bin 0x10000 NivolisAnton_2024.bin 0x 8000 partition-table.bin 0x10000 NivolisAnton_2024.bin 0x Serial port (CMN14 Connecting Chip is ESP32-00MD-V3 (revision 3) Features: WiFi, BT, Dual Core, 240MHz, VRef calibration in efuse, Coding Scheme None Crystal is 400Hz MAC: 8c:4b:14:36:50:c0 Uploading stub Stub running Changing baud rate to 460800 Configuring flash size Flash will be erased from 0x00001000 to 0x00006fff Flash will be erased from 0x00001000 to 0x00006fff Flash will be erased from 0x00001000 to 0x00008fff Compressed 22480 bytes to 14597 Wrote 22480 bytes (14597 compressed) at 0x0001000 in 0.8 seconds (effective 227.2 kbit/s) Hash of data verified. Compressed 1110752 bytes to 758062 Wrote 1110752 bytes to 758062 Wrote 3072 bytes (174 compressed) at 0x0001000 in 0.1 seconds (effective 503.9 kbit/s) Hash of data verified. Compressed 3072 bytes to 174 Wrote 3202 bytes (174 compressed) at 0x00010000 in 0.1 seconds (effective 30.0 kbit/s) Hash of data verified.				
Leaving Hard resetting via R	TS pin			
C:\DocWork\2021_VI	VA\Firmware\Ant	on>		
		Upon success, remove the cable between the electronic board and the PC. Then reconnect the flat microUSB cable from below the battery to the micro USB connector on the electronic board	Si la mise débrancl entre la e Puis recc microUS batterie sur l cart	e à jour est réussie, ner le câble micro-USB carte électronique et le PC. onnecter le câble plat B partant de sous la au connecteur micro-USB re électronique.
		Ensure that the white connector is still in place as indicated	Assurez- blanc est	vous que le connecteur : toujours bien en place

All dates and times are in the project's default time zone and formatting.

	Nivolis-ANTON Firmware Update Instructions			
Vivardis 🜌	VIVARDIS: QMS - template (QMS)			Date: 20240816 10:33
	Docui	Document: DOC-PROC13 - Work Instructions		Page: 4 / 4
(4)	5	Close Nivolis-Anton by paying attention to the cable location when closing	Fermer attentic	le boitier en faisant on aux câbles
PEC				
		Verify on the sever that the device	Vérifier	sur le serveur que le
		did communicate	disposit	if a bien communiqué